

# BW-10R-4P Instruction Manual

## Components



## Activation by original buttons



**<MENU> Button :**  
Long press : NAVI(Active) → AV1(Active) → AV2(Active).  
Short press : Switch screen to OEM Original Mode.

**<UP> Button :**  
Long press : Activate PIP and change the screen to PIP.

**<DOWN> Button :**  
Long press : View mode switching when using Omni-View.

**Other Button :**  
Long press : Show original screen for 3 seconds.

**UNIVERSAL MULTIMEDIA SYSTEM**  
**CAR VIDEO PIP INTERFACE WITH NAVI HDMI**

■ BZL-ECS06-1G	■ BENZ-ECS LVDS (06-09)	■ CVI-100N	■ SANTA FE TYPE (~2014)
■ BZSD-09-2G	■ BENZ TTL (2009)	■ CVI-200R-1G	■ GENESIS/EQUUS DIS1
■ BZR-S10-3G	■ BENZ-S ROUND (10~14)	■ CVI-200R-2G	■ GENESIS/EQUUS 7" INT
■ BZR- EC12-4G	■ BENZ-EC ROUND(12~15)	■ CVI-200R-3G	■ DIS2 TYPE (~2014)
■ BZR-ECS16-5G	■ BENZ-ECS ROUND(2014~)	■ CVI-300R-4G	■ GENESIS DH/K7 TYPE(2015~)
■ BZR-E17-6G	■ BENZ-E COAXIAL(2017~)	■ CVI-800D-6G	■ PALISADE NAVI
■ BW-10R-4P-2G	■ BMW ROUND (2010~2012)	■ CVI-50G-MOZEN	■ Grandeur HG/K7 Mozen(~2012)
■ BW-13R-6P-3G	■ BMW ROUND (2013~)	■ CVI-AN-MAL8	■ ALL NEW MALIBU8"/IMPALA
■ AUD-11R-2G	■ AUDI ROUND (2011~)	■ FD-S3-3G	■ FORD SYNC3
■ AUD-16R-3G	■ AUDI ROUND (2016~)		

POWER CAN1 I/F    IR    CAN2 I/F    12V OUT    CVBS    NAVI HDMI    LVDS OUT TOUCH    LVDS IN

## DIP Switch Setting

