

BZD-ECS14-NTG5.0

Components



VIDEO INTERFACE



POWER/CAN CABLE



LVDS CABLE



HDMI CABLE



LVDS IN/OUT PCB

DIP Switch Settings

OFF: ▲
ON: ▼

1 2 3 4 5

BENZ S-Class 12.1"
Around view Detection Setting

OFF: ▲
ON: ▼

1 2 3 4 5

BENZ S-Class 12.1"
Reverse gear Detection Setting

Exterior



Activation by original buttons



S-Class OEM Buttons

① Changing NAVI Screen — Press the button 2 seconds long.
NAVI Changing Original Screen — Press the button Short.

